

Troubleshooting Guide

DSC Systems

Changing and Adding User Codes:

PC 1555, PC 5010, PC 1616, PC 1832, PC 1864

Master Code: To program the master code, enter [*][5][current master code][40][new master code]. The master code must be four digits long. Press [#] to return to the ready state.

Additional Codes: Up to 32 additional access codes may be programmed.

Duress is user # 33

Program New Codes

Enter [*][5][master code][code number 01-32][new access code]. The code number is a double digit number for 01-32. Access codes must be four digits. Enter digits 0-9 only. Press [#] to return to the ready state.

Erase a Code

Enter [*][5][master code][code number 01-32][*]. Press the [#] to return to the ready state.

The master code cannot be erased.

PC 1500, PC 1550

Press [*] [5] [master code] the Memory, Bypass and Trouble light will begin to flash.

Enter [code number 1-6] [new 4 digit user code] [#]

The zone lights are used to indicate the program status of the 6 user codes:

(light off – code is not programmed, light on – code is programmed, light flashing – code is being programmed).

Activating the Chime Mode:

PC 1555, PC1575, PC 5010

LED Keypad

Enter [*][4] to turn the door chime feature on and off. When the command is entered the keypad buzzer will beep 3 times if the door chime feature is enabled and will sound one long beep if it is disabled.

LCD Keypad

Start with the panel in the disarmed mode, press [*] to enter the function list, then scroll to fine Door Chime. Press [*] or [4] to enable or disable the door chime feature. Press [#] to return to the ready state.

PC1500, PC 1550

Enter [*] [6] [master code] [6] to turn the door chime feature on and off. When the command is entered the keypad buzzer will beep 3 times if the door chime feature is enabled and will sound one long beep if it is disabled.

Resetting Clock (Loss of System Time and Date)

To reset press [*] [6], then the Master Code, then [1]. Enter the time in military (24hr) format 00:00 to 23:59. Then, enter date as MM DD YY, then #.

Ex. (time) 10:00 am is 1000 2:30 pm is 1430

Reset Battery:

Arm and then disarm the system. It may take a few minutes.

Bypassing Zone:

PC 1555, PC 5010, PC 1616, PC 1832, PC 1864

Press the * button then 1, then two digit zone number, then #.

PC 1500, PC 1550

Enter [*] [1] [user code] [single digit zone # to bypass] [#]

Reset Smoke Detector:

PC 1555, PC 5010, PC 1616, PC 1832, PC 1864

Press [*] [7] [2]

PC 1500, PC 1550

To cancel fire alarm press [#] within 30 seconds of alarm, otherwise the signal will be sent to the Central Station.

To reset the smoke detectors press [*] then hold down the [4] for several seconds.

Identifying Trouble or Service Conditions:

PC 1555, PC1575, PC 5010

A trouble will be indicated by the Trouble light which will remain on until the trouble condition is cleared. To view the type of trouble condition, press [*][2]. One or more zone lights will turn on, indicating the various trouble conditions.

Zones

Problems

- *1 Service Required. Press [1] and one or more of the zone lights corresponding to the following system troubles will turn on:
- | | |
|----------------------------|--------------------------------|
| 1 – Low Battery | 5 – General System Supervisory |
| 2 – Bell Circuit Trouble | 6 – Not Used |
| 3 – General System Trouble | 7 – PC5204 Low Battery |
| 4 – General System Tamper | 8 – PC5204 AC Failure |
- 2 Indicates Loss of AC power. When this trouble occurs, the trouble light will turn on but the keypad buzzer will not sound.
- 3 Telephone Line Trouble.
- 4 The panel has Failed to Communicate with the central station.
- *5 Zone Fault. Press [5] and the zone lights corresponding to the faulted zones will turn on.
- *6 Zone Tamper. Press [6] and the zone lights corresponding to the tampered zones will turn on.
- *7 Low Zone Battery. This trouble is generated when a wireless device exhibits a low battery condition. Press [7] one, two, or three times to view which devices are experiencing battery failure. The following will occur:
- | | Keypad Beeps | Keypad Display |
|-----------------|--------------|--------------------------------------|
| Press [7] once | 1 | Zones with low batteries. |
| Press [7] twice | 2 | Handheld keypads with low batteries. |
| Press [7] three | 3 | Wireless keys with low batteries. |
- 8 Loss of Time on System Clock.

***Indicates that if one of these trouble conditions comes up then you must press the number to check exact trouble.**

Example: You press *2 and zone 5 is lit, press 5 see which specific zone number is faulted.

PC 1500, PC1550

Press [*] [2] to see the trouble condition. When done press [#] to return to ready state.

Zones

Trouble

- | | |
|---|---------------------------|
| 1 | Defective Stand-by Batter |
| 2 | AC Power Failure |
| 3 | Fuse Failure |

- 4 Fail to Communicate
- 5 Smoke Detector Circuit Trouble
- 6 Loss of Time on System Clock